




COSTRUZIONE MACCHINE AGRICOLE
di
DODA ALDO & C SNC

USE AND MAINTENANCE MANUAL

MIXER FOR BIOGAS FERMENTERS

SERIES BG500



COSTRUZIONE MACCHINE AGRICOLE di DODA ALDO & C SNC
Via Sante Salmaso 18/20 46010 BUSCOLDO (MN) ITALY
Tel. +39 0376/410043 - Fax. +39 0376/410032
<http://www.doda.com> Email: doda@doda.com

INDEX

- 1 EC Declaration of conformity**
- 2 Safety instructions**
 - 2.1 Allowed employment
 - 2.2 Safety rules
 - 2.3 Symbols present in the manual
 - 2.4 Stickers
- 3 Description**
- 4 Functioning**
- 5 Technical features**
 - 5.1 Technical data
- 6 Installation**
 - 6.1 Mounting instructions
 - 6.1.1 Mixer with roof mounting
 - 6.1.2 Mixer with wall mounting
 - 6.1.3 Wall type mixer for the tank bottom
 - 6.2 Mixer mounting and installation
 - 6.2.1 General instructions
 - 6.2.2 Mixer with roof mounting
 - 6.2.3 Mixer with wall mounting
 - 6.2.4 Wall type mixer for the tank bottom
 - 6.3 Electric connection
 - 6.3.1 Setting of the mixer operating interval
- 7 Setting in motion**
 - 7.1 Checks at the first setting in motion
 - 7.2 Checks before each setting in motion / Daily checkings
 - 7.3 Mixer functioning
- 8 Maintenance program**
 - 8.1 Maintenance depending on wear level
 - 8.2 Current maintenance
- 9 Spare part list**

1 EC DECLARATION OF CONFORMITY

IN CONFORMITY WITH THE DIRECTIVE 2006/42/CE

We

DODA di Doda Aldo & c. s.n.c.

Via Contrargine sud, 3/5
46010 Canicossa (Mantova)

hereby declare under our own responsibility that the equipment, mentioned below,

MIXER SERIES BG

conforms to the requirements of the EC Directives 2006/42/CE and 94/9/CE concerning equipment intended for use in potentially Explosive Atmospheres (ATEX).

HARMONISED STANDARDS

DIN EN 982
DIN EN 12100-1
DIN EN 50014
DIN EN 13463-1

DIN EN 1127-1
DIN EN 12100-2
DIN EN 50021

The mixer is designed for biomass homogenization, also in the presence of non-homogeneous matter, and as a consequence is suitable for the installation on Biogas fermenters , available with both wall and roof mounting frame .

The here enclosed Declaration of conformity is valid only if all instructions recommended with this manual are carefully followed.

The mixer marking includes the following labels:

EX II 3GX 

CANICOSSA (MANTOVA)

ALDO DODA
CEO

.....
(Name, signature, corresponding)

Notes concerning the declaration of conformity

The present declaration states that the machines are in conformity with the strict provisions of the European Directive 2006/42/CE.

However, please take into account that even though the safety rules are carefully followed, the employment of each mixer implies certain risks.

Therefore, besides the general safety and accident prevention rules , we recommend that you should follow the safety instructions indicated in the present manual and the ones suggested by common sense.

2 SAFETY INSTRUCTIONS

2.1 Allowed employment

This BG500 mixer has to be employed only to homogenize biomass present in a digester or in fermentation tanks , such as slurry, non-homogeneous matter and other co-ferments.

With our mixer it is not allowed to mix the following substances:

- Mud obtained by clarification
- Solid bulky matters
- Bodies with sharp corners which could damage the mixer
- Medium mixed with foreign bodies (strings, ropes, plastic tapes, etc.....)

An employment different from that herewith indicated is not allowed.

Therefore the user as well as the mixer owner will be held responsible for any damage caused by an incorrect use.

For a correct employment:

- Follow the instructions of this manual;
- Respect the check and maintenance intervals indicated.

2.2 Safety rules

Follow the safety rules of the local authorities concerning Biogas plants, as well as the general safety provisions and the accident prevention regulations.

We recommend that any repair should be carried out either by an authorized mechanic assistance or by the manufacturer's technical assistance department.

In case, functioning defects arise due to the non-compliance with the hereby given use and maintenance instructions, the manufacturer could not be considered responsible.

2.3 Symbols used in this manual



Warning! Danger!

This sign warns you about a possible danger and suggests the most correct way you should behave in such situation.



Warning! Danger electricity!

This sign warns you about dangers that can cause damages to the mixers and to other present equipments as well as environmental degradation.



Warning! Flammable and explosive atmosphere!

The employment of the mixer in potentially explosive zones 0 and 1 can cause damages to things and injuries to persons with danger of death!

2.4 Stickers

The mixer is provided with the following stickers:



Read the instruction manual!



Warning! Danger!



Warning! Flammable and explosive atmosphere!




IMPORTANT: Before setting the machine in motion, fill it up with oil till the indicated level.

**LIVELLO
OLIO**

Fill up the machine with oil till the indicated level.
Check periodically the oil level.



This sticker reminds you to check the rotation direction of the electric motor before setting the machine in motion.



DATA PLATE INDICATING THE CONFORMITY WITH EC REGULATIONS:

- 1) NAME OF THE COMPANY
- 2) MONTH/YEAR OF PRODUCTION
- 3) SERIAL NUMBER
- 4) MACHINE TYPE

3 DESCRIPTION

The BG500 mixer is specifically designed for biogas fermentation and storage tanks, in order to homogenize slurry fermented substrates and co-ferments (food waste recycling,...).

The mixer employment is aimed at preventing the development of settled and floating layers in the tank.

It can also be employed in support of fixed mixers with no possibility of regulation, characterized by slow rotation (60-100 r.p.m.), which do not generate a satisfactory mixing.

To ensure an excellent mixing efficiency, the BG500 mixer is provided with an hydraulic device for the both horizontal and vertical regulation of the tilt angle of the propeller in the tank. (the propeller can swing up and down, right and left).

The medium and gas tightness of the digester is made sure by a strong expansion joint which is firmly fixed both on the mixer drive line and on the wall /or roof mounting plate, by means of a flange coupling.

The surfacing and the consequent emission of gas bubbles, which form in the fermented medium, are made easier by the vigorous and at the same time soft mixing of the bacteria. That prevents an uncontrolled ferment "swelling".

The mixer functioning time can change according to needs.

It is generally recommended that the motor rotation speed (r.p.m.) should be adjusted according to the type of substrate to be treated, by using an inverter. That can avoid the unnecessary functioning and optimize the electric power consumption.

During mainly the loading and starting phases, the user has to set the correct functioning time and the suitable motor rotation speed.

Usually we advise a starting phase with a high rotation speed which has to be gradually reduced during normal operating.

No white spots have to come up to the surface (sulphur deposition) and no substance has to deposit at the bottom of the tank.

Furthermore it is necessary to check the tank maximum level, above all in case of high silage or great manure quantity.

In case of an increase of the tank maximum level or of sulphur deposition, extend the mixer operating time and, if necessary, speed up the motor revolutions per minute.

The BG500 is standard provided with a 600mm diameter 3 vane propeller and a strong vibration-resistant frame, suitable to support the gear box and designed for both wall or roof mounting.

4 FUNCTIONING

According to the requested installation, the mixer is provided with a roof or wall mounting frame.

Usually the mixer arm inclines towards the left with regards to the tank wall, but on request the mixer can be supplied with arm leaning towards the right.

The machine is equipped with a hydraulic device, through which the mixing propeller direction can be regulated, both horizontally and vertically.



The propeller turns anticlockwise.

The propeller can turn in the opposite direction to the recommended one only few seconds. That can cause serious damages.

The mixer can be provided by an auxiliary PTO, which can be used only exceptionally and only under constant surveillance.

In this case the allowed revolutions per minutes are 540 r.p.m.

With full tank, the rotation direction is recognizable only through the thrust effect generated by the fluid present in the tank, which should move towards its middle.

The functioning of the mixer in the opposite direction to the recommended one could cause strong vibrations, as well as serious damages to both the mixer and the tank.

On account of the different composition of the substrate to be mixed, it is necessary to adjust the mixing propeller of immersion depth and to check that the propeller vanes are completely covered by fluid during mixing.

During functioning no vortex or splashes have to be noticed in the fermenting medium.



The mixer has to work always in a enough full tank and with the propeller vane covered at least 0,5m by the fluid; otherwise a strong side vibration above all around the Motor-Drive line unit will be noticed, which could damage the mixer.

Even during normal operating the mixer could swing sideways.

Anyway, if the vibration is not higher that ● 3,5 mm/s, that is not dangerous in consideration of the provided vibration-resistant frame. Besides, this vibration can be prevented by increasing the revolutions per minute by means of an inverter.



On the contrary, by too low rotation speed, strong side vibrations could occur, therefore if necessary raise the revolutions per minute in order to avoid possible damages to the mixer and the tank.

If, in spite of the compliance with the above-mentioned instructions, you do not obtain a satisfactory mixing performance (e.g. because of a large tank diameter or a high content of dry matter) , contact promptly the dealer or the manufacturer .

The dealer or the manufacture can not be considered responsible for damages due to incorrect employment of the mixer.

If the tank is filled with already fermented substrate coming from other Biogas containers, there could be material floating on the surface, due to a high dry matter content. That could also occur in case of a fault in the Biogas plant and the consequent unforeseen mixer stopping.



In case a great quantity of floating wastes is present, before starting the mixer, take the necessary steps, which of course have to be previously agreed with the dealer or the manufacturer of the machine.

Attention! The mixer drive line can be damaged by extreme side thrust caused by excess floating materials.

The propeller vane can undergo excessive stress which could affect negatively the tank stability.

5 TECHNICAL FEATURES

The data indicated refer to a standard supply.

The manufacturer reserves the right to introduce changes without prior notice.

1. All components touching the fluid , as well as all parts situated in the tank, are made of stainless steel.
2. Mixer drive shaft in oil bath.
3. Al Widia mechanical seal on the drive shaft
4. Control of the drive line lubrication oil level through an oil expansion tank, set next to the electric motor.
5. Heavy duty drive line with high resistant industrial belt, propeller rotation speed 500 r.p.m. / with 1450 r.p.m. motor, at 50 Hz.
6. Self-cleaning three vane propeller.
7. Hydraulic regulation of the mixing propeller (up and down, right and left) through a hand pump with oil reservoir and connection pipings, standard supplied.
8. Roof or wall mounting frame.

5.1 Technical data

The data indicated refer to a standard supply.

The manufacturer reserves the right to introduce changes without prior notice.

Mixer type	BG500 15kW	BG500 18,5kW
Power /Motor type	15kW/4 poli	18,5kW/4 poli
Rated power	15 kW	18,5 kW
Rated voltage	400 V	400 V
Frequency	50 Hz	50 Hz
Revolutions per minute	1450 rpm	1450 rpm
Electric motor noise level	69dB	70dB
Voltage	28 Amp.	34 Amp.
Starting current	7	6,2
Power factor cos φ	0,86	0,86
Temperature probe	PTC 160°	PTC 160°
Substrate temperature	70°	70°
Gear ratio	3:1	3: 1
Propeller diameter	600 mm	600 mm
Drive line oil quantity	42 liters Esso Spartan EF150	42 litres Esso Spartan EF150
Hydraulic oil quantity for hand pump	5 litre Nuto 68 (or equivalent)	5 litre Nuto 68 (or equivalent)
Total weight	680 kg	700 kg

Mixer type	BG500 2,2m long for the tank bottom	BG500 3,15m long for the tank bottom
Power /Motor type	18.5kW/4 poli	18,5kW/4 poli
Rated power	18.5 kW	18,5 kW
Rated voltage	400 V	400 V
Frequency	50 Hz	50 Hz
Revolutions per minute	1450 rpm	1450 rpm
Electric motor noise level	70dB	70dB
Voltage	34 Amp.	34 Amp.
Starting current $\cos \varphi$	6.2	6,2
Power factor	0,86	0,86
Temperature probe	PTC 160°	PTC 160°
Substrate temperature	70°	70°
Gear ratio	3:1	3: 1
Propeller diameter	600 mm	600 mm
Drive line oil quantity with hydraulic oil for hand pump	20 liters Esso Spartan EF150	25.5 litres Esso Spartan EF150
Total weight	322 kg	453 kg

6 INSTALLATION

6.1 Mounting instructions

The biogas mixer can be supplied with wall or roof mounting frame.

The different installation types have been specially designed to suit the different tank and digester manufacturing features, as well as the different biogas plant locations and working conditions.

To obtain an optimal mixing besides the suitable homogenization of the fermented substrate, the technical design department or the dealer or the manufacturer have to check the correct positioning of the mixer.

The location choice has to take into account that lift trucks have to access easily to that area.



Before installing the mixer, ask for the written authorisation of the person in charge with the wall static calculations.

Doda is not responsible for possible tank damages caused by an unsuitable installation or use of the mixer.



Explosion danger due to a thunderbolt!
Arrange for a lightning protection system.



Explosion danger due to the Absence of a main equipotential bonding!
The grounding connection has to be executed only by a skilled electrician.

6.1.1 Mixer with roof mounting

To install the mixer, make a hole of 1400 x 700 mm in the roof. Usually we recommend to place the mixer at least 4-5 m far from the raw material input area, so that the propeller radius of action could generate an uniform homogenization of the solid matters introduced.

The mixer position has to fit any other mixers already present.

The mixer thrust effect has not to be altered.

To ensure the correct mixer functioning, we recommend that it should be installed at least 1 meter far from the roof edge, so that the propeller can work also with fermented substrates characterized by a high dry substance content.



During the design and the carrying out of the hole in the roof, remove the insulating material (if present).



A resistant sealing between the mounting frame and the concrete surface is ensured only if the surfaces surrounding the installation plate are polished and even.



Danger of explosion due to biogas emissions!

To ensure the mixer frame sealing, the tank cover has to be even enough, i.e. it has not to have hollows or unevenness!

Check the correct grounding connection of the mixer!

6.1.2 Mixer with wall mounting

To install the mixer, make a hole of 700 x 700 mm in the wall.

If you have to install the mixer on a pre-existing tank drill a hole with a diameter of 700mm. Attention! Check if there are any electric cables, pipes, heat pipings, etc.. on the tank wall, before making the hole.

It has to be installed at a such height, so that the distance between the upper corner of the wall opening and the higher corner of the tank wall is 0,5m. That ensures an optimal fluid homogenization.

Usually we recommend to place the mixer at least 4-5m far from the raw material input area, so that the propeller radius of action could generate an uniform homogenization of the solid matters introduced.

The mixer position has to fit any other mixers already present.

The mixer thrust effect has not to be altered.

The standard provided mounting frame has a 30° tilt to the left, in order that the flow of the mixed product turns in a clockwise direction.

Normally the vortex generated by the mixing vanes makes the rotary motion of the mixed product easier.



During the design and the carrying out of the hole in the wall, take into account that from the external side of the tank there has to be room enough for the manoeuvres necessary for mixer installation and dismantling.

Furthermore take into account the suitable distance between other possible tanks or equipments.



A resistant sealing between the mounting frame and the concrete surface is ensured only if the surfaces surrounding the installation plate are polished and even.

Remove the insulating material situated on the tank outside side (if present).

In case of unevenness around the tank hole, remove it.



Remove or repair any tank wall defects, which could come out of its dismantling, according to the laws in force concerning building.

An incorrect fixing of the mixer and the consequent vibrations due to mixing could both damage the mixer and cause the leak of fermented substrate as well as environmental damages.

Therefore, in case of doubts, we suggest that an expert should check possible faults to be improved. All that carried out has to be documented and attached with photos.



Danger of explosion due to biogas emissions!

To ensure the mixer frame sealing, the tank cover has to be even enough, i.e. it has not to have hollows or unevenness!

Check the correct grounding connection of the mixer!



Near the mixer there have to be no trees, equipments or anything that could endanger its correct functioning.

In case the mixer weight is excessive with regards to the tank wall bearing capacity, the mounting frame can move away from the fixing systems.

The accidental leak of product from the tank can cause environmental damages.



The entry of any motor vehicle to the digester area without authorization is strictly forbidden.



Danger of explosion due to biogas emissions!

To know at which distance the motor vehicles have to stay from the potentially explosive atmospheres, consult the regional government safety rules in force concerning biogas plants.

6.1.3 Wall type mixer for the tank bottom

To install the mixer on the tank wall, it is necessary make a hole suitable for the drive line passage and for the bolts fixings (if it is a sheet steel).

Attention! Check if there are any electric cables, pipes, heat pipings, etc.. on the tank wall, before making the hole.

Before installing it, take into account the position and the overall dimension of the propeller, which has not to be within the range of action of other machines or structures installed inside the tank.


The mixer position has to fit any other mixers already present.

The mixer thrust effect has not to be altered.

The standard provided mounting frame has a 30° tilt to the right.

Normally the vortex generated by the mixing vanes makes the rotary motion of the mixed product easier.

In case of installation in sheet steel tank, it is necessary to use a counter- flange (supplied together with the mixer) which has to be installed inside the tank with through bolts.



During the design and the carrying out of the hole in the wall, take into account that from the external side of the tank there has to be room enough for the manoeuvres necessary for mixer installation and dismantling.

Furthermore take into account the suitable distance between other possible tanks or equipments.



A resistant sealing between the mounting frame and the concrete surface is ensured only if the surfaces surrounding the installation plate are polished and even.

Remove the insulating material situated on the tank outside side (if present).

In case of unevenness around the tank hole, remove it.



Remove or repair any tank wall defects, which could come out of its dismantling, according to the laws in force concerning building.

An incorrect fixing of the mixer and the consequent vibrations due to mixing could both damage the mixer and cause the leak of fermented substrate as well as environmental damages.

Therefore, in case of doubts, we suggest that an expert should check possible faults to be improved. All that carried out has to be documented and attached with photos.



Danger of explosion due to biogas emissions!

To ensure the mixer frame sealing, the tank cover has to be even enough, i.e. it has not to have hollows or unevenness!

Check the correct grounding connection of the mixer!



Near the mixer there have to be no trees, equipments or anything that could endanger its correct functioning.

In case the mixer weight is excessive with regards to the tank wall bearing capacity, the mounting frame can move away from the fixing systems.

The accidental leak of product from the tank can cause environmental damages.



The entry of any motor vehicle to the digester area without authorization is strictly forbidden.



Danger of explosion due to biogas emissions!

To know at which distance the motor vehicles have to stay from the potentially explosive atmospheres, consult the regional government safety rules in force concerning biogas plants.

6.2 Mixer mounting and installation

6.2.1 General instructions

The electric motors installed on our mixers are suitable for an outside installation, therefore humidity and dirt resistant, according to their IP55 protection degree.

Anyway, for a correct motor and gearbox operating, the outside temperature has not to be lower than -10°C and higher than $+40^{\circ}\text{C}$.

A correct motor ventilation has to be ensured.

Prevent suction and discharge openings from blocking up and clogging due to rough dust.



Follow the safety rules of the local authorities concerning Biogas plants, as well as the general safety provisions and the accident prevention regulations.

Hazard of injuries in case of not correctly fixed parts!



Instruction for mixer transport and installation

Attention! Transport the mixer only with suitable motor vehicles.

The loading and unloading of the machine can be carried out by means of:

- a lift truck (fig.1) or
- a hoisting crane (fig.2).

N.B.: the carrying capacity of the sling has to be seven times as much as the machine total weight (if it is made of a textile fibre).


WARNING! Never lift the machine by catching on the weakest parts of the structure (delivery pipes, etc...) or on moving parts, but use the lifting points foreseen on the machine (fig.3)!

Before lifting the machine, check if it is well-balanced.

Never move abruptly or bump the stainless steel parts with the forks of the lift truck.

Stopping under a hanging load during mixer lifting, transport or unloading, is strictly forbidden!

Never leave any hanging load unattended!





Warning! Flammable and explosive atmosphere!

No mounting or installing operations have to be carried out for any reason in potentially explosive atmosphere!

The mixer can be installed and employed only in the allowed zones!

As concerns the position of the dangerous zones, refer to the Classification of the potentially explosive zones which the user and the designer have to follow strictly!

Notify any change made in potentially explosive areas influenced by the mixer and check if the new arrangement complies with the rules in force.



Hazard of injuries because of the fall of mixer components!

Wear accident prevention shoes and safety helmet!

Hazard of injuries due to mixer components with sharp edges!

Wear gloves!

Both during working and inspection phases, wear always proper clothing (overalls, gloves, helmet, accident prevention shoes, fastened clothes, etc...).



If necessary use safety equipment (safety belt, sling, gas detector, oxygen mask, etc..)



In case mounting and installation in a potentially explosive atmospheres, before starting, apply for the necessary authorization to the person in charge with it, who has to provide you with the corresponding manuals and ask you to fill the necessary forms in compliance with laws.



Employ the machine in a well-lit place.



Since the gases released by liquid manure are poisonous, check that:

- the work area is enough ventilated;
- the machine is not employed close to flames.



Never inspect the slurry pit alone!

If you loose your balance or if you feel faint due to fumes, ask for help immediately!



Only adults can use the machine and absolutely in a place not accessible to children.

Before any operation, check the stability of the whole working unit (machine and tractor).

Do not carry out any repair, adjustment or maintenance operations if the unit is working or supplied.

Cover the tank if you have not to work in it.

We recommend that the machine should be employed with all protections properly positioned, according to the instructions mentioned in the previous paragraphs, in order to avoid any contact with moving parts.

Do not damage or remove these protections.



During operating, maintenance or adjustment, the rubber parts of the machine (gaskets, etc...) have not to come into contact with oil, grease or oil derivatives.



In case you do not use the machine for long time, keep it in a dry place and protected against bad weather.

6.2.2 Mixer with roof mounting

Before mounting the mixer, check the dimensions of the hole made in the roof. Remove any possible impurities present on the surface where you have to install it.

Check the flatness of the mounting and sealing surface and take the necessary improvements.

We recommend that you should use a suitable sealant between the mounting frame and the foreseen installation surface.

To make the 12mm holes, use a drill plate. Before executing the first hole, line the plate with the roof opening, so that the mixer could be correctly fixed with the anchor bolts.

In order not to move the drill plate, set the first fixing anchor bolt immediately after the first hole has been made and press the plate firmly on the tank roof. Then you can go on with all other holes.

To make the fixing operations easier, all other anchor bolts can be set after the mounting frame installation.



In order to insert the anchor bolts easily and in the best way, clean the holes made with compressed air and remove dust present on the hermetic surfaces.

Attention! Follow the installation instructions of the fixing anchor bolts!



Put anti-seize grease on the bolt threads, to prevent the anchor bolts from locking before reaching the torque. **After having built the mixer into the roof, tighten the anchor bolts.**

Check the bolt tightening after a few days.

6.2.3 Mixer with wall mounting

Before mounting the mixer, check the dimensions of the hole made in the wall, as well as the correct mixer positioning.

Any changes have to be previously agreed with the manufacturer absolutely before the mounting.

Remove any possible impurities or insulating material present on the surface where you have to install it.

Check the flatness of the mounting and sealing surface and take the necessary improvements.

In areas exposed to gas and on hermetic concrete surfaces, we recommend that you should use a suitable sealant.

To make the 12mm holes, use a drill plate. Before fixing the drill plate, make a hole.

Attention! Follow the instructions for anchor bolt fixing.

After having fixed the first bolt, position the drill plate on the tank wall by means of a forklift truck.

Before making the left over holes, check again the exact positioning of the mixer, so that it could be correctly fixed with the anchor bolts supplied.

For further mounting operations, follow the instructions given in paragraph 6.2.1 *General instructions*.

6.2.4 Wall type mixer for the tank bottom

Before mounting the mixer, check the dimensions of the hole made in the wall, as well as the correct mixer positioning.

Any changes have to be previously agreed with the manufacturer absolutely before the mounting.

Remove any possible impurities or insulating material present on the surface where you have to install it.

Check the flatness of the mounting and sealing surface and take the necessary improvements.

In areas exposed to gas and on hermetic concrete surfaces, we recommend that you should use a suitable sealant.

For a perfect seal between mixer and tank use specific mastics for metals and concrete.

In the concrete tanks, make 12 mm holes and use the counter-flange as drill plate.

Attention! Follow the instructions for anchor bolt fixing.

For sheet steel tank use stainless steel M14 screws as long as necessary to install the inner counter-flange. Use screws by keeping the bolt head inside the tank; use washers suitable for M14 screws and seal with specific biomass-resistant mastic suitable for sheet steel.

ùOutside the tank tighten the bolts with self-locking nuts.

For further mounting operations, follow the instructions given in paragraph 6.2. 1 *General instructions*.

6.3 Electric connection

Our mixer is standard supplied without electric switchboard.

The motor starting has not to be direct but progressive (i.e. provided with soft starter, inverter, etc.), so that the mixer reaches the nominal rotation speed in about 3-5 sec. Avoid any sharp starting or stopping!

We recommend the use of an inverter!



Warning! Danger electricity!

The electric connection has to be carried out only by skilled workers and in a place protected against atmospheric precipitations, following the directives in laws concerning safety and accident prevention provisions.

Furthermore follow scrupulously the precise pertaining indications concerning electric connections (i.e. cable section, safety rules, connection of a protection conductor, etc.).

Use only components in compliance with the regulations!

In potentially explosive atmospheres it is allowed to carry out electric connections only if authorized!



Danger of explosion due to biogas emissions!

Check if the electric cables are correctly connected and protected!



The cable has to be long enough so that the mixer could tilt without problems!

Risk of crushing!

Do not place any electric cable near the hydraulic device and rotating parts!

Prevent the cable from:

- getting entangled!
- hanging down!
- being damaged!
- loosing or falling!



Protect the motor against excessive overheating by means of a suitable device: e.g. circuit breaker with a phase failure protection.

The motor is equipped with thermistors, so that an additional thermal protection of the machine could be used. (TMS / Thermal management system)

Attention! In case of an installation in compliance with ElexV regulations, employ only TMS trip device (trip device for cold conductors).



The PTC thermistors/probes have a maximum measurement and testing of 2,5 V. Install counters to set the functioning interval.

The supplied motors are protected against dust and water splashes, according to their protection degree.

In case of ice or snow, take all necessary safety steps.

The motor supply line has to be carried out in conformity with the data indicated in the connection box, situated on the motor lower part, and with those indicated on the control panel.

6.3.1 Setting of the mixer operating interval



Hazard of damages to the mixer and injuries to persons in case of employment in the opposite rotation direction to that indicated!

The operating interval has to be programmed on the control panel of the Biogas plant!

The optimal operating period and pause depends on the manufacturing characteristics, as well as on the working conditions and the fluid to be treated.

Only authorized workers have to program the control panel of the Biogas plant.

As indicative value, at the beginning the mixer can be programmed as follows:

- mixing time about 8-10 minutes and
- 30 minute pause.

In case of unsatisfactory mixing it is necessary to extend the operating time and decrease the pause length.

A continuous functioning is also allowed.

7 SETTING IN MOTION

7.1 Check at the first setting in motion

Check the motor rotation direction: the motor has to turn **clockwise** as indicated by the arrow on the motor.

Start the motor for any seconds to check if the motor cooling fan turn rightwards.

The mixing propeller has to turn leftward, i.e. in a **anticlockwise direction**.

If the propeller is not clearly visible, it is necessary to check the rotation direction of the mixing propeller of the activation motor.



Hazard of damages to the mixer and injuries to persons in case of employment in the opposite rotation direction to that indicated!

According to the electric polarization of the 400V connection, the motor rotation could be wrong!

Check if the mixer is correctly fixed on the foreseen installation surface.

Check if all bolts set on the mixer are correctly fastened.

Both moving parts of the hydraulic direction adjusting device and the bearing bushes of the fixing bolts have to be lubricated.



Set the unit in motion only after having checked the oil level in the drive line, in the gearbox and in the hand pump for the hydraulic regulation.

The correct oil quantity is the following:

- 42 litres of Esso Spartan EP150 for the drive line;
- 5 litres of Nuto 68 oil (or equivalent) for the hand pump.

In the oil expansion tank, the oil level has not to be higher than 1cm (Attention! During functioning the oil volume increases!)

In order to check oil, act as follows:

- unscrew inlet and vent caps;
- After having filled the machine with oil up, wait at least 3 hours before setting the unit in motion.
- Screw caps again.
- Check oil level periodically: it has never to be beyond the indicated level.

N.B. During filling up and check, the drive pipe, has to be as vertical as possible.



- 1) Drive line oil discharge
- 2) Drive line oil level, vent and inlet.



The wall type mixers for tank bottom are provided with an oil compensator and a hand pump in order to keep under pressure the oil inside the drive line.

This device is useful for counterbalancing the pressure of the liquid – present in the fermenter – on the drive line Widia seal.

The pressure gauge measures the pressure inside the drive line (see fig.5).

The correct pressure, which has to be exerted on the oil, is calculated according to the height of the liquid present into the tank: i.e. each 10m = 1 bar (e.g.: if the tank liquid level is equal to 5m, the pressure gauge will indicate 0.5 bar)

In order to raise oil pressure, move the hand pump lever (see fig. 6); in order to reduce oil pressure open the discharge valve indicated in figure 7.



7.2 Checks before each setting in motion/ daily checkings



Each time you set the unit in motion, check if the network or better the supply line complies with the regulations in law.

Compare the voltage indicated on the motor plate with that supplied by the network.

Check and lubricate periodically all the moving parts (about each 50 operating hours). Remove old and spent lubricant.



Danger of explosion due to biogas emissions!

Check *daily* if the rubber parts of the expansion joint are damaged or torn.



Hazard of damages to the mixer or injuries to persons!

Check *daily* the stability of the fixing bolts put on the direction adjusting device and on the hydraulic jack.

Check if they are damaged or torn.

In case of damages or unsuitable fixing, the mixer has to be stopped immediately to remove the failure found out.

All bolts and nuts have to be fixed firmly as indicated in the table in *Chapter 8* and then *daily* checked. All corresponding operations have to be documented.

7.3 Mixer Functioning



Hazard of damages to the mixer and injuries to persons

Follow the instructions indicated in *Chapter 2*.

For a correct installation of the propeller, take into account the mixer tilt!



Danger of explosion! Due to the overheating of the intermediate and lower bearings, caused by non-lubrication.

Check always the correct oil level in the drive line.



Danger of explosion!

From the digester or the fermented product tank, explosive or flammable gases can come out!

Smoking or using flame or any other flammable substance is strictly forbidden!



Hazard of damages to the mixer!

Check that nothing could block the propeller!

The propeller has to be enough covered by the product to be mixed!

During the mixing, pay attention to possible unusual noises! (which can be caused by the non-lubrication, loosened parts, failures regarding the motors, gearbox, bearing or drive shaft, etc...)

Keep the mixer always free from snow or ice!



Hazard of damages to the mixer!

The presence of foreign bodies such as strings, ropes, plastic tapes can unbalance the mixing propeller, which consequently can damage the bearings as well as the whole unit.

These foreign bodies can also damage the mechanical seal.

Rarely, and only in case of fixed installation of the equipment, the material can be corroded.

Anyway these phenomena are mainly due to stray currents (i.e. potential displacement, faulty grounding connection) or electrochemical reactions (high acidification of co-ferment or of biowaste, usually at a temperature higher than +45°C).

8 MAINTENANCE PROGRAM

Check all bolt and nut set on the mixer, the frame and all other components after the first 2 working hours and then after 100 operating hours (at the latest after 1 working month).

Control the fixing anchor bolts on the mixer mounting frame and if necessary tighten them further on!

SCREW TORQUE in Nm						
Bolt	M8	M10	M12	M16	M20	M24
Class A2/ A4-70	16	32	56	135	280	450
8.8 grade galvanized Class A2/ A4 - 80	20	41	70	170	330	570
Anchor bolt M12-15/110 A4	50					



Condensate forming in the motor terminal board!

Condensate can form in the terminal board of the flameproof electric motors. For this reason, we suggest that at regular intervals (at least once a year) you should stop the mixer and remove the condensing water with a suitable absorbent cloth.

Before carrying out the above mentioned operations, read carefully the instructions in *paragraph 8.2*.

8.1 Maintenance depending on wear level

All moving parts are subjected to wear, whose level depends on working time, operating conditions and on the shocks they undergo.

Both the mechanical seal as well as the drive shaft bearing have to be replaced each 20.000 operating hours.

Expansion joint rubber part wear out can vary, depending on the machine use level and the exposition to the atmospheric agents.

8.2 Current maintenance

The propeller waste depends on the working time and on the quality of the product to be mixed.

If the power absorption is clearly lower than the highest nominal charge, you have to replace the worn-out propeller, as well as the self-locking M30 fixing bolts.

During the replacement, check if the installation surfaces are clean.

All maintenance operations carried out have to be wholly documented (see the documentation concerning the maintenance and repair operations).



Before maintenance, disconnect the ON/OFF main switch and make sure it can not be connected again accidentally.
Affix a danger signal!



Follow scrupulously the safety rules indicated in *Chapter 2* and the instructions concerning mixer installation in *Chapter 6*.



Danger of explosion!

During repair or maintenance, lower the tank filling level according to needs (above all in case of maintenance to a wall mounting mixer).

Warning! In potentially explosive atmospheres, **it is strictly forbidden to:**

- carry out any repair, maintenance operations, i.e. any work that can generate flames or sparks.
- Bring any flammable source (es. Free flames, thermal sources, not flameproof equipments, etc..)

Employ **absolutely ONLY NON-SPARKING TOOLS** (that is valid also for drills, hollow drill bits, chisels, etc....)



Before carrying out any operation, apply for the authorization of the person in charge with safety and fill correctly the permission request form to operate in potentially explosive atmospheres, which has to be duly signed by the person responsible.

AUTHORIZATION TO OPERATE IN POTENTIALLY EXPLOSIVE ATMOSPHERES

Fill in only the parts that concern you. Delete the parts that don't concern you.

Authorization to carry out welding, drilling, polishing, hammering and chiselling, and any other operation which can generate flames or sparks.

This document is necessary also in case of employment of not flameproof equipments.

A.

1. Customer.....Building site address
Tel.Person in charge with safety.....
2. Location and work type
.....
3. Permit from to (hours) for the period of time
4. For workshop / companyAddress
Person in charge with safety

B. Dangerous areas in the surroundings

In the working place, in the buildings, of the equipments, etc.	Person in charge	Building site address	Telephone
1			
2			
3			
4			

C. Necessary safety measures taken by

1 Checking of the pipe and equipment seal used

2 Fire protections and other safety measures

- ☐ a. Water supply and extinguisher to put out the fire
- ☐ b. Fire hose
- ☐ c. Block off the area.
- ☐ Workers ☐ Employees ☐ Supervisors ☐ Firemen
- ☐ d. Remove flammable matters, possible steam, gas or dust
- ☐ e.
- ☐ f.

3. Signals (road, track plant, etc)

- ☐ a. with red flags (20 m on both sides of the work site)
- ☐ b. by means of signs
- ☐ c. barriers for tracked vehicle, detours for tankers, etc...

4. Protection against welding sparks

- ☐ a. Covering of close pipings
- ☐ b. Use of protective walls, a protection for the covering surface (if necessary keep it wet)
- ☐ c. Work Interruption in case of trains traffic
- ☐ d. Keeping a minimum distance of from tank trucks, tanks etc. at the hazard of fire
- ☐ e. Covering of grids, channel pits and lighting
- ☐ f.

5. Works to be carried out inside or close to tanks, equipments, pits, pipes, dismantled plant components, in narrow rooms etc. Further precautions.

- ☐ a. Transit permit.....No.....dtd.....
- ☐ b. Work permit..... No.....dtd.....
- ☐ c. Safety documentation for electric systems.....No.....dtd.....
- ☐ d.....

6.

- ☐ a. Daily notification of work beginning in case of B1, 2, 3,4
- ☐ b. Daily notification of work end in case of B1, 2, 3, 4

7.

- ☐ a. Control of the safety measures marked by (name)
- ☐ b. Check of the building site at the work end by (name).....

D Agreement about responsibility concerning dangerous areas

Work beginning notification.....dtd.....by.....
For B1 safety measure C point
For B2 safety measure C point
For B3 safety measure C point
For B4 safety measure C point

Permit issued on

Date

Company Director Signature

DOCUMENTATION ABOUT REPAIR AND MAINTENANCE

DATE	HOUR	WORK CARRIED OUT	SIGNATURE OR STAMP OF THE PERSON IN CHARGE OF WORK DONE


DOCUMENTATION ABOUT REPAIR AND MAINTENANCE

DATE	HOUR	WORK CARRIED OUT	SIGNATURE OR STAMP OF THE PERSON IN CHARGE WITH WORK DONE


DOCUMENTATION ABOUT REPAIR AND MAINTENANCE

DATE	HOUR	WORK CARRIED OUT	SIGNATURE OR STAMP OF THE PERSON IN CHARGE WITH WORK DONE

9. Spare part list



BGS500 A PARETE con attacco PTO







ENGLISH PART DESCRIPTION

U.M.	Quantità	Codice	Descrizione
NR	1,00	E3704	15KW ELECTRIC MOTOR UNIT EXPLODED VIEW OF BG500 WITH WALL INSTALLATION
NR	1,00	3713	GLV KW15-22 MOTOR FRAME
NR	1,00	3714	PULLEY HTD Z112 8M 35MM DIAM.
NR	1,00	3716	PULLEY HTD Z38 8M 85 42MM DIAM.
NR	1,00	3718	SPACER 76/42 DIAM. 13MM THICK
NR	1,00	3720	LOCK WASHER FOR PULLEY Z112
NR	1,00	3721	LOCK WASHER FOR PULLEY Z38
NR	1,00	3723	GLV CLOSURE PLATE
NR	4,00	3725	GLV STUD
NR	2,00	3726X	S.S. PIN
NR	2,00	3727	TIE ROD
NR	1,00	3734X	S.S. PROTECTION CASING
NR	4,00	BUL5206	S.S. NUT M12 UNI5587
NR	1,00	BUL5231	S.S. BOLT M12X30 UNI5739
NR	2,00	BUL5236	BOLT S.S. M12X60 UNI5737
NR	6,00	BUL5253	S.S. SELF-LOCKING NUT M14 UNI7473
NR	3,00	BUL5284	S.S. BOLT M14X45 UNI5739
NR	4,00	BUL5303	S.S. SELF-LOCKING NUT M16 UNI7473
NR	1,00	BUL5331	S.S. BOLT M16X35 UNI5739
NR	1,00	BUL5911	S.S. BOLT M14X40 UNI5933
NR	3,00	BUL5998	S.S. GROWER WASHER M12 UNI1751
NR	7,00	BUL5999	S.S. GROWER WASHER M14 UNI1751
NR	1,00	BUL6000	S.S. GROWER WASHER M16 UNI1751
NR	1,00	ELE111A	15KW 4 POLE FLAMEPROOF ELECTRIC MOTOR
NR	1,00	PVC355	BELT HTD 1280 8M 85






ENGLISH PART DESCRIPTION

U.M.	Quantità	Codice	Descrizione
NR	1,00	E3702	EXPLODED VIEW OF THE BGS500 WALL INSTALLATION PLATE
NR	2,00	2380B	HYDRAULIC JACK 60MM EXT.DIAM. 30X150
NR	2,00	3670X	S.S. RETAINER
NR	1,00	3728	GLV FORK
NR	2,00	3729	GLV CLAMP
NR	1,00	3730	GLV FORK FORK
NR	2,00	3731	GLV PIN
NR	4,00	3732X	S.S. WASHER 8MM THICK
NR	1,00	3733	GLV PISTON BRACKET
NR	1,00	3737X	S.S. INSTALLATION PLATE , (15°TILT ON THE LEFT, 18°TILT DOWNWARD)
NR	4,00	3738	GLV HINGE
NR	1,00	3739	GLV RING
NR	1,00	3745	GLV FLARED PISTON BRACKET
NR	1,00	3747X	S.S. INSTALLATION PLATE , (15°TILT ON THE RIGHT, 18°TILT DOWNWARD)
NR	4,00	BUL5283	S.S. BOLT M14X40 UNI5739
NR	24,00	BUL5303	S.S. SELF-LOCKING NUT M16 UNI7473
NR	16,00	BUL5332	S.S. BOLT M16X40 UNI5739
NR	8,00	BUL5334	S.S. BOLT M16X50 UNI5739
NR	12,00	BUL5404	S.S. SELF-LOCKING NUT M20 UNI7473
NR	12,00	BUL5435	S.S. BOLT M20X60 UNI5739
NR	12,00	BUL5436	S.S. BOLT M20X70 UNI5739
NR	2,00	BUL5450	LOCK NUT GLVD M22 AUTOBL.UNI7473
NR	1,00	BUL5606	GLV BOLT M22X140 UNI5737
NR	1,00	BUL5607	GLV BOLT M22X120 UNI5737
NR	4,00	BUL5658	BLACK SCREW M10X45 UNI5931
NR	4,00	BUL5999	S.S. GROWER WASHER M14 UNI1751
NR	1,00	PSC494	RUBBER EXPANSION JOINT DN250 PN10
NR	4,00	RAC255	GLV GREASE CUP 90° 1/8"



Trasmissione da 4.5m Per motore da 15 Kw



DATA	SCALA	CODICE DISEGNO
29/04/08		E3701



ENGLISH PART DESCRIPTION

U.M.	Quantità	Codice	Descrizione
NR	1,00	E3701	EXPLODED VIEW OF THE 4,5M LONG DRIVE LINE OF THE BG500 MIXER WITH WALL MOUNTING
NR	1,00	3700X	160MM S.S. DRIVE PIPE
NR	1,00	3701X	1500MM S.S. DRIVE PIPE
NR	1,00	3702X	1500MM S.S. CENTRAL DRIVE PIPE
NR	1,00	3703X	1500MM S.S. DRIVE PIPE ON MOTOR SIDE
NR	1,00	3704	DRIVE PIPE ON MOTOR SIDE
NR	1,00	3705X	354MM S.S. SHAFT, 55MM DIAM.
NR	1,00	3707	4440MM SHAFT FE60, 35MM DIAM.
NR	1,00	3709	310MM IRON SHAFT, 50MM DIAM.
NR	1,00	3710X	S.S. PROPELLER 600MM DIAM.
NR	1,00	3711X	S.S. MECHANICAL SEAL COVER
NR	1,00	8017B	29MM BUSH, 55MM DIAM. IN CHROMIUM
NR	4,00	BUL5183	S.S. BOLT M10X35 UNI5739
NR	18,00	BUL5253	S.S. SELF-LOCKING NUT M14 UNI7473
NR	18,00	BUL5285	S.S. BOLT M14X50 UNI5739
NR	6,00	BUL5287	S.S. BOLT M14X60 UNI5739
NR	1,00	BUL5451	S.S. SELF-LOCKING NUT M22 UNI7473
NR	4,00	BUL5997	S.S. GROWER WASHER M10 UNI1751
NR	1,00	BUL6074	KEY C45K 10X8X90 UNI6604
NR	3,00	BUL6076	KEY C45K 10X8X70 UNI6604
NR	1,00	BUL7313	SEEGER RING J80 UNI7437
NR	1,00	BUL7316	SEEGER RING J 85 UNI7437
NR	1,00	CUS115	BEARING 6209 - MADE IN GERMANY
NR	2,00	CUS124	BEARING 1208 EKTN9/C3 SKF
NR	2,00	CUS136	BUSH H 208 SKF
NR	1,00	CUS196	BEARING 6208 SKF
NR	1,00	CUS222	BEARING 3309 ATN9 SKF
NR	1,00	CUS284	BEARING 6309 FAG
NR	1,00	GTP154	STATIC WIDIA SEAL 45 MM DIAM
NR	1,00	GTP155	ROTATING WIDIA SEAL 45 MM
NR	1,00	GTP165	OIL SEAL 55.80.8
NR	1,00	GTP168	SPLASH GUARD H175
NR	1,00	GTP174	METRIC O RING 40MM DIAM 1,50MM THICK
NR	2,00	GTP185	O RING 235 GB4312 78,97MM DIAM. 3,53MM THICK
NR	1,00	GTP407	O RING 241 GB4387 98,02MM DIAM 3,53MM THICK
NR	1,00	RAC112	OIL VENT CAP KMU M3/4"
NR	1,00	RAC318	CAP M3/8" INOX316






ENGLISH PART DESCRIPTION

U.M	Quantit	Codice	Descrizione
NR	1,00	E3700	15KW ELECTRIC MOTOR UNIT EXPLODED VIEW OF BG500 WITH ADDITIONAL PTO
NR	1,00	3712	SPLINED SHAFT
NR	1,00	3713	GLV KW15-22 MOTOR FRAME
NR	1,00	3715	PTO PULLEY HTD Z112 8M 85 35MM DIAM.
NR	1,00	3716	PULLEY HTD Z38 8M 85 42MM DIAM.
NR	1,00	3718	SPACER 76/42 DIAM. 13MM THICK
NR	1,00	3720	LOCK WASHER FOR PULLEY Z112
NR	1,00	3721	LOCK WASHER FOR PULLEY Z38
NR	1,00	3724	GLVN PTO CLOSURE PLATE
NR	4,00	3725	GLV STUD
NR	2,00	3726X	S.S. PIN
NR	2,00	3727	TIE ROD
NR	1,00	3734X	S.S. PROTECTION CASING
NR	1,00	3735	GLV PTO PROTECTION CASING
NR	1,00	3736	GLV PTO PROTECTION CASING COVER
NR	2,00	BUL5101	S.S. SELF-LOCKING NUT M8
NR	6,00	BUL5130	BOLT S.S. M8X16 UNI5739
NR	4,00	BUL5184	S.S. BOLT M10X40 UNI5739
NR	4,00	BUL5206	S.S. NUT M12 UNI5587
NR	1,00	BUL5231	S.S. BOLT M12X30 UNI5739
NR	2,00	BUL5236	BOLT S.S. M12X60 UNI5737
NR	6,00	BUL5253	S.S. SELF-LOCKING NUT M14 UNI7473
NR	4,00	BUL5281	S.S. BOLT M14X30 UNI5739
NR	3,00	BUL5284	S.S. BOLT M14X45 UNI5739
NR	4,00	BUL5303	S.S. SELF-LOCKING NUT M16 UNI7473
NR	1,00	BUL5331	S.S. BOLT M16X35 UNI5739
NR	1,00	BUL5911	S.S. BOLT M14X40 UNI5933
NR	4,00	BUL5997	S.S. GROWER WASHER M10 UNI1751
NR	3,00	BUL5998	S.S. GROWER WASHER M12 UNI1751
NR	7,00	BUL5999	S.S. GROWER WASHER M14 UNI1751
NR	1,00	BUL6000	S.S. GROWER WASHER M16 UNI1751
NR	4,00	BUL6005	S.S. GROWER WASHER M8 UNI751
NR	1,00	ELE111A	15KW 4 POLE FLAMEPROOF ELECTRIC MOTOR
NR	1,00	PSC691	CATCH 50MM DIAM. M10X30
NR	1,00	PVC355	BELT HTD 1280 8M 85

Impianto idraulico



DATA	SCALA	CODICE DISEGNO
18/04/07		E3705



ENGLISH PART DESCRIPTION

U.M.	Quantità	Codice	Descrizione
NR	1,00	E3705	EXPLODED VIEW OF THE HYDRAULIC SYSTEM OF THE BG500 MIXER WITH WALL MOUNTING
NR	1,00	PSC586	HAND PUMP PMI25-5
NR	8,00	BUL5975	COPPER WASHER 3/8" D.17X23 1,5MM THICK
NR	8,00	RAC139	NIPPLE MALE 3/8"/MALE 3/8"
NR	4,00	IDR406	4000MM HYDRAULIC HOSE WITH 90°ELBOW FEMALE 3/8"- FEMALE 3/8"


Miscelatore di profondità sfilabile con trasmissione 3.15 mt


Technical drawing of a depth-adjustable mixer with a 3.15m transmission. The drawing shows a side view of the mixer assembly with various components labeled with part numbers: 1311293 (top housing), 1311231 (top cover), 1311319 (top flange), 1311318 (middle housing), 1311134 (central shaft), 1311139 (lower housing), and M131311016 (motor). A detail view of the motor and transmission assembly is shown on the right.

BUSCOLD (MN) TEL. 0376.410043
ITALY FAX. 0376.410032
BGS500 di profondità modello estraibile v.f.


DESCRIZIONE	ESEGUITO IL AGGIORNAMENTO DEL		
MATERIALE	16/09/10	16/09/10	
A termine di legge la vettura la riproduzione o comunicazione a terzi senza nostra approvazione scritta			
DISEGNATORE	PESO	SCALA	UNITA' MIS. QUANTITA'
P.D.			mm
PANTOGRAFO	SPESORE	CODICE DISEGNO	
		M131311019	

NUMERO PARTE	QTÀ	COMMENTI
1311134	1	Passante per bgs 500
1311139	1	Passante per bgs 500
1311231	1	Cassano fissaggio alla vasca
1311293	1	Lamiera di chiusura
1311318	2	Lamiera rinforzo 01 esterno vasca
1311319	2	Lamiera rinforzo 02 esterno vasca
3710X	1	Elica BGS500
M131311016	1	BGS500 di profondità trasmissione completa
M131311017	1	Supporto lama BGS500
Motore Me 180 LT 22Kw 4p	1	
UNI 5588 - M20	36	
UNI 5588 - M27	8	
UNI 5737 - M27 x 180	8	
UNI 5739 - M20 x 40	12	
UNI 5739 - M20 x 50	24	
UNI 5739 - M27 x 55	32	
saracinesca 700	1	Descrizione






DATA	SCALA	CODICE DISEGNO
26/05/09	1:7	3700XCMPL







Gruppo motrice da 18.5Kw + PTO



DATA	SCALA	CODICE DISEGNO
04/06/07		E3707



NUMERO PARTE	QTÀ	COMMENTI
1311097	1	Staffa supporto compensatore
BUL5975	7	RONDELLA RAME PIA. 3/8"D. 17X23 S.1,5
IDR105	1	Pompa semplice effetto 5 litri
IDR534	1	TUBO 1/4" R1 L. 160 M3/8"+F3/8" GIREVOLE
IDR525	1	TUBO 1/4" R1 L. 850 M3/8"+F3/8" GIREVOLE
RAC120004	1	Manometro 0-4 glicerina
RAC139	2	NIPPLIO M3/8"-M3/8" OLEOD.
RAC185	1	RACC. "T" F3/8"-F3/8"-F3/8" OLEOD.
RAC268	1	RIDUZIONE F1/4"-M3/8" OLEOD.
RAC399	1	hstpvc 2.3 precaricato a 1 bar
RAC421	1	RIDUZIONE M3/8"-M3/4" OLEOD.
UNI 5739 M10x35	4	

 BUSCOLLO (MN) ITALY		TEL. 0376.410043
		FAX. 0376.410032
DESCRIZIONE	BGS 500 profondità impianto idraulico	
MATERIALE	ESEGUITO IL AGGIORNAMENTO DEL	
	16/09/10	16/09/10
A termine di lavoro è richiesta la quotazione e compilazione a cura nostra nostra approvazione scritta.		
DISEGNATORE	PESO	SCALA UNITA' MIS. QUANTITA'
P.D.		mm
PANTOGRAFO	SPESSORE	CODICE DISEGNO
		M131311021

Miscelatore di profondità fisso con trasmissione 2.2 mt


Technical drawing of a fixed depth mixer with transmission, showing components and dimensions. The drawing includes a motor (Motore Me 180 LT 22Kw 4p) connected to a shaft assembly. Key components and dimensions are labeled:


- 1311317: Bracket for the motor.
- 1311322: Bracket for the motor.
- UNI 5588 - M20: Bracket for the motor.
- 1311226: Bracket for the motor.
- UNI 5739 - M20 x 90: Bracket for the motor.
- M131311017: Bracket for the motor.
- M131311024: Bracket for the motor.
- 3710X: Bracket for the motor.
- UNI 5739 - M20 x 40: Bracket for the motor.
- UNI 5588 - M20: Bracket for the motor.
- UNI 5739 - M20 x 90: Bracket for the motor.

Dimensions: 951, 2545, 1594.


DDDA	BUSCOLDÒ (MN)		TEL. 0376.410043	
	ITALY		FAX. 0376.410032	
DESCRIZIONE	BGS500 di profondità modello fisso			
MATERIALE	ESEGUITO IL AGGIORNAMENTO DEL			
	16/09/10			
A servizio di legge è valida la riproduzione in compilazione a terzi senza nostra approvazione scritta.				
DISEGNATORE	PESO	SCALA	UNITÀ	MIS. QUANTITÀ
P.D.				mm
PANTOGRAFO	SPESSORE		CODICE DISEGNO	
			M131311018	


NUMERO PARTE	QTÀ	COMMENTI
1311226	1	Attacco BG a vasca LIPP modello fisso
1311317	3	Piastra fissaggio BG
1311322	3	Tubo rinforzo
3710X	1	Elica BGS500
M131311017	1	Supporto lama BGS500
M131311024	1	BGS500 di profondità trasmissione completa
Motore Me 180 LT 22Kw 4p	1	
UNI 5588 - M20	16	
UNI 5739 - M20 x 40	12	
UNI 5739 - M20 x 90	4	





DATA	SCALA	CODICE DISEGNO
26/05/09	1:7	3700XCMPL




		BUSCOLD (MN) ITALY		TEL. 0376.410043 FAX. 0376.410032
DESCRIZIONE		tubo di trasmissione lato motore con tenute		
MATERIALE		15/06/09	ESEGUITO IL AGGIORNAMENTO DEL 15/06/09	
A termine di legge è vietata la riproduzione o comunicazione a terzi senza nostra approvazione scritta				
DISEGNATORE P.D.	PESO 10.9	SCALA mm	UNITA' MIS. QUANTITA' mm	
PANTOGRAFO	SPESSORE	CODICE DISEGNO E1311003		


Q
Q
Q
Q



E3707



NUMERO PARTE	QTÀ	COMMENTI
1311097	1	Staffa supporto compensatore
BUL5975	7	RONDELLA RAME PIA. 3/8"D. 17X23 S.1,5
IDR105	1	Pompa semplice effetto 5 litri
IDR534	1	TUBO 1/4" R1 L. 160 M3/8"+F3/8" GIREVOLE
IDR525	1	TUBO 1/4" R1 L. 850 M3/8"+F3/8" GIREVOLE
RAC120004	1	Manometro 0-4 glicerina
RAC139	2	NIPPLIO M3/8"-M3/8" OLEOD.
RAC185	1	RACC."T" F3/8"-F3/8"-F3/8" OLEOD.
RAC268	1	RIDUZIONE F1/4"-M3/8" OLEOD.
RAC399	1	hstpvc 2.3 precaricato a 1 bar
RAC421	1	RIDUZIONE M3/8"-M3/4" OLEOD.
UNI 5739 M10x35	4	

 BUSCOLLO (MN) ITALY		TEL. 0376.410043
		FAX. 0376.410032
DESCRIZIONE	BGS 500 profondità impianto idraulico	
MATERIALE	ESEGUITO IL	AGGIORNAMENTO DEL
	16/09/10	16/09/10
A termine di legge è obbligatoria la compilazione e compilazione a firma propria nostra approvazione scritta.		
DISEGNATORE	PESO	SCALA UNITA' MIS. QUANTITA'
P.D.		mm
PANTOGRAFO	SPESSORE	CODICE DISEGNO
		M131311021

COSTRUZIONE MACCHINE AGRICOLE di DODA ALDO & C SNC
Via Sante Salmaso 18/20 46010 BUSCOLDO (MN) ITALY
Tel. +39 0376/410043 - Fax. +39 0376/410032
<http://www.doda.com> Email: doda@doda.com